


RAB Lighting is committed to creating high-quality, affordable, well-designed and energy-efficient LED lighting and controls that make it easy for electricians to install and end users to save energy. We'd love to hear your comments. Please call the Marketing Department at 888-RAB-1000 or email: marketing@rablighting.com

TEMP-XXX-850 TEMP-XXX-850/XXCP







IMPORTANT

READ CAREFULLY BEFORE INSTALLING LED TEMP LIGHT. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.

RAB temp light must be wired in accordance with the National Electrical Code and all applicable codes. Proper grounding is required for safety. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.

WARNINGS:

- Operating temperature: -30°C to 60°C (-22°F to 140°F).
- Please read this manual carefully before use, make sure the application is in accordance with the instructions.
- To reduce the risk of electric shock and fire, do not exceed string maximum wattage including any additional string loads. Maximum number of connection lamps:
 - 60W 10PCES Max
- 100W 6PCES Max
- 150W 4PCES Max
- · This device is suitable for dry and damp locations.
- · Disconnect the power to avoid shock when the equipment is wet.
- · This device is not intended for use with emergency exits.
- The product should not be installed in heat and sealed environment and corrosive gases, and other places, so as not to affect the service life.
- This luminaire must be installed, tested and maintained by professionals using special equipment.
- Please check the product carefully after opening the package. If any products are damaged, please keep the original package and contact your local dealer.

CAUTION:

RAB's Temporary work light, including its LEDs, housing, power cord, LED driver, and internal wiring meet all UL product certification requirements from our factory. However, when these luminaires are modified in any way by cutting and removing the NEMA 5-15 Plug with the specific intent to splice the luminaire into a 277 VAC circuit, the luminaire "will not" meet the UL product certification standard because the receptacle on the luminaire will be energized at 277 VAC, not the receptacle's "intended" 120 VAC operation.

INSTRUCTION

TEMP LIGHT SERIES



RAB Lighting is committed to creating high-quality, affordable, well-designed and energy-efficient LED lighting and controls that make it easy for electricians to insta and end users to save energy. We'd love to hear your comments. Please call the Marketing Department at 888-RAB-1000 or email: marketing@rablighting.com

INSTALLATION INSTRUCTION


- 1. Turn off the power before installation.
- 2. The installation steps for a single lamp are Step 1 and Step 2 only.
- 3. The installation steps for 2 or more products repeat Steps 1 through Step 3.
- 4. Close the cap of the last lamp if there is no further connection to other lamps.


Caution - Maximum number of lamp connections: 60W - 10PCS, 100W - 6PCS, 150W - 4PCS.

Lamps may not work as advertised if the number of connected lamps exceeds the allowable quantity. Lamp can work normally after removing redundant lamps.


TEMP-XXX-850(Cable length: 8ft)

TEMP-XXX-850/XXCP(Cable length: 60W - 15ft; 100W - 25ft; 150W - 35ft)





Connect the plug and socket to make sure 2 or more lamps be jointed together, and rotate the buckle 90 degree to make sure the lamps connected more firm.



Note: These instructions do not cover all details or variations in equipment nor do they provide for every possible situation during installation, operation or maintenance.



Easy Answers

rablighting.com Tech Help Line
Visit our website for product info Call our experts: 888 722-1000

e-mail

Free Lighting Layouts Answered online or by request

Answered promptly - sales@rablighting.com