
AN3 VANDALPROOF FIXTURES





INSTALLATION INSTRUCTIONS

High Pressure Sodium or Metal Halide

IMPORTANT READ CAREFULLY BEFORE INSTALLING FIXTURE.

RETAIN INSTRUCTIONS FOR FUTURE REFERENCE. RAB Vandalproof fixtures must be wired in accordance

with the National Electrical Code and applicable local codes. Proper grounding is required for safety.

limited ventilation or high ambient temperatures. WARNING: Make certain power is OFF before installing or maintaining fixture.

LOCATION

Fixture should be ceiling mounted. Fixture should be

located at least 12" away from any structural detail

Installation should be done by a qualified electrician.

and from adjoining wall. Fixture should not be

HPS and Metal Halide Vandalproof fixtures are for

outdoor use and should not be used in areas with

MOUNTING.

Box Mounting:

below).

- Remove refractor and socket mounting plate from fixture. Remove close-up plug in back (see mounting note
- Connect fixture leads to supply leads with wire nuts. Install lamp and replace refractor and socket mounting.
- plate with notches of lens inserted into slots of fixture.
- NOTE: It is recommended that fixture be attached securely by drilling through knockouts in back of fixture

Conduit Mounting:

recessed.

fixture. Remove close up plug(s) in housing for desired. conduit entrance (see mounting note below)

Remove refractor and socket mounting plate from

- Connect fixture leads to supply leads with wire nuts. 4. Install lamp and replace refractor and socket mounting
- plate with notches of lens inserted into slots of fixture.
- and attaching to mounting surface (hardware not supplied). When drilling fixture, care must be taken to avoid

drilling close to ballast or within 1/4" of sides of fixture. All unused entries must be plugged. Use weatherproof silicone sealant to insure proper seal.

VAN3 INSTALL

(continued)

TAMPERPROOF SCREWS RAB Vandalproof fixtures are shipped with both For maximum security, insert tamperproof screws into

WIRING Connect the black fixture lead to the black supply

standard screws and tamperproof screws.

Torx screwdriver (catalog #Vandriver, not supplied).

LIGHT

BLACK

WHITE

all four corners of the lens and tighten with Center Pin

INSTRUCTIONS


Connect the white fixture lead to white supply lead. Fixture ground screw must be connected to supply

- PHOTOEYE INSTALLATION
- Remove close-up plug on desired side of fixture. Install Photoeye as per diagram.

A photoeye control may be installed in the field.

Remove refractor and socket mounting plate.

RE-LAMPING.



BLACK

WHITE

CAUTION: Prior to installing, check that the lamp is of proper type and wattage. Observe lamp manufacturer's recommendations on lamp operation, ballast type and burning positions.

Disconnect power. Make sure fixture and lamp are Loosen screws holding refractor. Remove refractor and install lamp. cool enough to touch.

CLEANING_

CAUTION: Be sure fixture temperature is cool

enough to touch. Be sure power is off.

Close refractor and re-install screws.

non abrasive glass cleaning solution.

Clean refractor and lens with a cloth moistened with

Fixture is wired properly.

TROUBLESHOOTING CHECKLIST. Check that: Proper lamp is installed. Lamp is not faulty.

IN EQUIPMENT, NOR DO THEY PROVIDE FOR EVERY POSSIBLE CONTIN-

GENCY TO BE MET IN CONNECTION WITH INSTALLATION, OPERATION

Fixture is grounded properly. RAB Electric Manufacturing, Inc. THESE INSTRUCTIONS DO NOT COVER ALL DETAILS OR VARIATIONS

Line voltage at the fixture is proper.


- 170 Ludlow Avenue Northvale, New Jersey 07647-0670 U.S.A. 201 784 8600
- 201 784 0077 (Fax) 888 RAB 1000 moc.clewdar.rawrar

OR MAINTENANCE.

7/97

VAN6

Vandalproof Fixture



LOCATION Fixture should be located on wall or ceiling at least 18°

WARNING Make certain power is OFF before installing or maintaining fixture.

MOUNTING

screws provided.

Remove lens from fixture.

should not be recessed.

important.

INSTALLATION of TAMPERPROOF SCREWS. RAB Vandalproof fixtures are shipped with standard

2. Attach universal crossbar to junction box with two

3. Thread mounting nipple (provided) through center hole

below any overhang or other structural detail. Fixture

- screws installed and tamperproof screws shipped with the fixture packed separately.

of fixture and into the crossbar. Tighten locknut.

Install lamp and replace lens.

driver (catalog #vandriver).

Connect fixture leads to supply leads with wire nuts.

For maximum security, insert tamperproof screws into both

corners of the lens and tighten with Tamperproof screw-

VAN6 INSTALLATION INSTRUCTIONS

(continued)

WIRING. Connect the black fixture lead to the black supply lead.

2. Connect the white fixture lead to white supply lead.

Make sure connections are secure using wirenuts, crimp-

on lugs or other approved connecting devices.

Make sure fixture and lamp are cool enough to touch.

3. Fixture ground lead must be connected to supply

RE-LAMPING

GROUND

BLACK A

WHITE A

Close lens and re-install screws

Caution: Be sure fixture temperature is cool enough to touch.

Disconnect power.

ground.

120 volt Photocell mounted in backbox. /PC w White lens

 Proper lamp is installed. Lamp is not faulty. Line voltage at the fixture is proper. Fixture is wired properly.

FACTORY INSTALLED OPTIONS

201 784 0077 (Fax)

Fixture is grounded properly.

add suffix to catalog number

Caution: Prior to installing, check that the lamp is of proper type and wattage. Observe lamp manufacturer's recommendations on lamp operation, ballast type and burning positions. Remove screws holding lens, remove lens and set aside.

Clean Reflector and lens with non abrasive glass cleaning

BLACK

WHITE

VANG

EQUIPMENT NOR DO THEY PROVIDE FOR EVERY POSSIBLE CONTINGENCY TO BE MET IN CONNECTION WITH INSTALLATION, OPERATION OF MAINTENANCE.

TROUBLE SHOOTING CHECKLIST.

solution or detergent. Rinse with clean water.

SE INSTRUCTIONS DO NOT COVER ALL DETAILS OR VARIATIONS IN

3/96

RAB Electric Manufacturing, Inc. 170 Ludlow Avenue Northvale, New Jersey 07647-0970 U.S.A. 201 784 8600