# **INSTRUCTIONS** X17<sup>™</sup> FLOODLIGHT TRUNNION KIT INSTALLATION



RAB Lighting is committed to creating high-quality, affordable, well-designed and energy-efficient LED lighting and controls that make it easy for electricians to install and end users to save energy. We'd love to hear your comments. Please call the Marketing Department at 888-RAB-1000 or email: marketing@rablighting.com



## IMPORTANT

#### READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.


RAB fixtures must be wired in accordance with the National Electrical Code and all applicable local codes. Proper grounding is required for safety. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.

WARNING: Make certain power is OFF before installing or maintaining fixture.

### INSTALLATION

#### Notice: 0° - 180° of angle adjustment.

- 1. Feed Housing wires through Bracket A. Secure Bracket A to Housing with (2) Screws (provided) as shown in Fig. 1.
- 2. Feed Housing wires through Bracket B and secure to Bracket A with (2) Screws (provided) as shown in Fig. 2.
- 3. Wire the **Housing** leads to supply wires using UL listed wire connectors according to NEC and local codes.
- 4. To adjust the Housing angle loosen (2) Screws on Bracket B, set to desired angle and tighten (2) Screws.



Note: These instructions do not cover all details or variations in equipment nor do they provide for every possible situation during installation, operation or maintenance.



Easy Answers

© 2021 RAB LIGHTING Inc. Visit our website for product info TX17 60W/80W Trunnion Kit - IN-0621 73726-RAB **Tech Help Line** Call our experts: 888 722-1000 e-mail Answered promptly - sales@rablighting.com Free Lighting Layouts Answered online or by request