


INSTRUCTIONS

CYLINDER INSTALLATION




RAB Lighting is committed to creating high-quality, affordable, well-designed and energy-efficient LED lighting and controls that make it easy for electricians to install and end users to save energy. We'd love to hear your comments. Please call the Marketing Department at 888-RAB-1000 or email: marketing@rablighting.com


Wall Mount



CD34FA3W-10-508-XX



CD34FA4W-20-508-XX



CD34FA6W-36-708-XX

Ceiling Mount



CD34FA4SP-20-509-XX



CD34FA6SP-30-709-XX

IMPORTANT

READ CAREFULLY BEFORE INSTALLING FIXTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE.


RAB fixtures must be wired in accordance with the National Electrical Code and all applicable local codes. Proper grounding is required for safety. THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.

WARNING:


- Make certain power is OFF before installing or maintaining fixture. No user serviceable parts inside.
- Fixture is suitable for wet location.
- Fixture must be mounted a minimum of 4 feet above ground level.

WALL MOUNT WHAT'S IN THE BOX


Important: For wet locations, Gasket must be used.




Fixture



Gasket



(3) P3 Wire Nuts




(2) M4*30

Tapping Screws


WALL MOUNT INSTALLATION

1. Remove (2) M4*8 Screws on two sides and separate Junction Box Adaptor Plate from the Fixture. (Fig. 1)

Fig: 1



(2) M4*8 Screws




Junction Box
Adaptor Plate

WALL MOUNT INSTALLATION (cont'd)

2. Stick Gasket and fix Junction Box Adaptor Plate with (2) M4*30 Tapping Screws on the wall. (Fig. 2)
(Warning: The mark "UP" direction must be installed upside.)

Fig: 2



3. Connect the wires with (3) P3 Wire Nuts according to Wiring Diagram. (Fig. 3) (Fig. 31)

Fig: 3



(3) P3 Wire Nuts

INSTRUCTIONS

CYLINDER INSTALLATION




RAB Lighting is committed to creating high-quality, affordable, well-designed and energy-efficient LED lighting and controls that make it easy for electricians to install and end users to save energy. We'd love to hear your comments. Please call the Marketing Department at 888-RAB-1000 or email: marketing@rablighting.com

WALL MOUNT INSTALLATION (cont'd)


4. Mount back the **Fixture** on **Junction Box Adaptor Plate** with **(2) M4*8 Screws** tightly. (Fig. 4)

Fig: 4




5. Unscrew **Plug A** to adjust the output distribution selectable and CCT (Default: Output distribution selectable-Full; CCT-3000K). When set down, screw back **Plug A**. (Fig. 5)

Fig: 5




6. Unscrew **Plug B** to turn ON/OFF Photocell (Default: Photocell-OFF). When set down, screw back **Plug B**. (Fig. 6)

Fig: 6




CEILING MOUNT WHAT'S IN THE BOX

Important: For wet locations, caulk the seam between the fixture and ceiling.



Fixture




Cord Clamp with
Screw C



Thread
Lock



(2) M4*30
Tapping Screws



(3) P3 Wire Nuts




(2) P2 Wire Nuts

CEILING MOUNT INSTALLATION


1. Unscrew **Junction Box Adaptor Plate** and **Canopy** off the **Fixture** counterclockwise. Remove **Screw A** from **Canopy** and separate **Junction Box Adaptor Plate** and **Canopy**. (Fig. 7)

Fig: 7




2. Fix **Junction Box Adaptor Plate** into junction box with **(2) M4*30 Tapping Screws**. (Fig. 8)

Fig: 8




3. Unscrew **Plug A** to adjust the CCT (Default-3000K). When set down, screw back **Plug A**. (Fig. 9)

Fig: 9



4. Fix **Canopy** back to the **Fixture**. (Fig. 10)

Fig: 10



INSTRUCTIONS


CYLINDER INSTALLATION




RAB Lighting is committed to creating high-quality, affordable, well-designed and energy-efficient LED lighting and controls that make it easy for electricians to install and end users to save energy. We'd love to hear your comments. Please call the Marketing Department at 888-RAB-1000 or email: marketing@rablighting.com

CEILING MOUNT INSTALLATION (cont'd)


5. Connect **Tether Cable** on **Canopy** to **Tether Slot** in **Junction Box Adaptor Plate**. (Fig. 11)



6. Connect the wires with (3) **P3 Wire Nuts** and (2) **P2 Wire Nuts** according to **Wiring Diagram**. (2) **P2 Wire Nuts** are for dimming wires. (Fig. 12) (Fig. 32)




7. Align the holes on **Canopy** and **Junction Box Adaptor Plate** to fix **Canopy** back to **Junction Box Adaptor Plate** counterclockwise and tighten them with **Screw A**. (Fig. 13)



PENDANT CORD/ PENDANT POLE MOUNT


Important: For wet locations, caulk the seam between the fixture and ceiling.

1. Unscrew **Junction Box Adaptor Plate** and **Canopy** off the **Fixture** counterclockwise. Remove **Screw A** from **Canopy** and separate **Junction Box Adaptor Plate** and **Canopy**. (Fig. 14)




PENDANT CORD/ PENDANT POLE MOUNT (cont'd)


2. Pass **Thread Lock** through the **Cord** and tighten it securely. (Fig. 15)




3. Unscrew **Plug A** to adjust the CCT (Default-3000K). When set down, screw back **Plug A**. (Fig. 16)



4. Fix **Junction Box Adaptor Plate** into junction box with (2) **M4*30 Tapping Screws**. (Fig. 17)



5. Connect **Tether Cable** on **Canopy** to **Tether Slot** in **Junction Box Adaptor Plate**. (Fig. 18)



INSTRUCTIONS

CYLINDER INSTALLATION




RAB Lighting is committed to creating high-quality, affordable, well-designed and energy-efficient LED lighting and controls that make it easy for electricians to install and end users to save energy. We'd love to hear your comments. Please call the Marketing Department at 888-RAB-1000 or email: marketing@rablighting.com

PENDANT CORD/ PENDANT POLE MOUNT (cont'd)


6. Pass **Cord Clamp** through the **Cord**. Adjust **Cord** length according to requirement and tighten **Cord Clamp with Screw C**.
A minimum of 6 inches will be needed for connecting to the power supply wires located in the junction box.

Fig: 19




7. Connect the wires with (3) **P3 Wire Nuts** and (2) **P2 Wire Nuts** according to **Wiring Diagram**. (2) **P2 Wire Nuts** are for dimming wires.(Fig. 20) (Fig. 32)

Fig: 20



8. Fix **Canopy** back to **Junction Box Adaptor Plate** and tighten them with **Screw A**. (Fig. 21)

Fig: 21




CORD TO POLE CONVERSION

Note: Please refer to RAB CD34STEM-X. Poles are sold separately.


1. Remove **Cord Clamp with Screw C**, **Canopy**, **Tether Cable with Screw B**, **Junction Box Adaptor Plate with Screw A**. Discard **Thread Lock**. (Fig. 22)

Fig: 22




2. Insert **Cord** through **Pole** section. Screw **Pole** section to **Fixture**. Add up to 3 more **Pole** sections as required. Each pole section is 12" long. A minimum of 6 inches will be needed for connecting to the power supply wires located in the junction box. (Fig. 23)

Fig: 23



3. Thread **Cord** onto **Hollow Stud** and tighten them securely. (Fig. 24)

Fig: 24



INSTRUCTIONS

CYLINDER INSTALLATION


RAB

RAB Lighting is committed to creating high-quality, affordable, well-designed and energy-efficient LED lighting and controls that make it easy for electricians to install and end users to save energy. We'd love to hear your comments. Please call the Marketing Department at 888-RAB-1000 or email: marketing@rablighting.com

CORD TO POLE CONVERSION (cont'd)


4. Unscrew **Plug A** to adjust the CCT (Default-3000K). When set down, screw back **Plug A**. (Fig. 25)

Fig: 25




5. Unscrew **M10 Outside Hexagonal Hollow Nut** to **Canopy** and fix **Canopy** to **Pole** through **M10 Outside Hexagonal Hollow Nut**. (Fig. 26)

Fig: 26




6. Fix **Junction Box Adaptor Plate** into junction box with (2) **M4*30 Tapping Screws**. (Fig. 27)

Fig: 27



6. Connect **Tether Cable** on **Canopy** to **Tether Slot** in **Junction Box Adaptor Plate**. (Fig. 28)


Fig: 28



CORD TO POLE CONVERSION (cont'd)


8. Connect the wires with (3) **P3 Wire Nuts** and (2) **P2 Wire Nuts** according to **Wiring Diagram**. (2) **P2 Wire Nuts** are for dimming wires. (Fig. 29) (Fig. 32)

Fig: 29



9. Fix **Canopy** back to **Junction Box Adaptor Plate** and tighten them with **Screw A**. (Fig. 30)

Fig: 30



Note: These instructions do not cover all details or variations in equipment nor do they provide for every possible situation during installation, operation or maintenance.

WIRING DIAGRAM

Fig: 31




Fig: 32



INSTRUCTIONS

CYLINDER INSTALLATION



RAB Lighting is committed to creating high-quality, affordable, well-designed and energy-efficient LED lighting and controls that make it easy for electricians to install and end users to save energy. We'd love to hear your comments. Please call the Marketing Department at 888-RAB-1000 or email: marketing@rablighting.com

CLEANING & MAINTENANCE

CAUTION: Be sure fixture temperature is cool enough to touch.
Do not clean or maintain while fixture is energized.


1. Do not open fixture to clean the LED. Do not touch the LED.
2. Do not touch reflector.
3. Do not clean any fixture surface with wood-base cleaning material such as paper towels or tissues.

TROUBLESHOOTING

1. Check that the line voltage at the fixture is correct. Refer to wiring directions.
2. Is the fixture grounded properly?

DIMENSIONAL DRAWINGS


Wall Mount




CD34FA6W-36-708-XX

DIMENSIONAL DRAWINGS (cont'd)

Wall Mount




CD34FA4W-20-508-XX




CD34FA3W-10-508-XX

Ceiling Mount



CD34FA6SP-30-709-XX



CD34FA4SP-20-509-XX



© 2022 RAB LIGHTING Inc.
Cranbury, New Jersey 08512 USA

CD34FA-IN 0822

Easy Answers

rablighting.com
Visit our website for product info

Tech Help Line
Call our experts: 888 722-1000

e-mail
Answered promptly - sales@rablighting.com

Free Lighting Layouts
Answered online or by request

RAB WARRANTY: RAB's warranty is subject to all terms and conditions found at rablighting.com/warranty.