# RAB

W22

FIELD ADJ.

ADJUSTABLE THROW

Highlight
Building
Perimeter

Adjustable throw wall packs!

## W22—Now with Lightcloud Blue!

That's not all you can control…

Selectability doesn't end with forward throw on the W22!
Each model has four selectable wattages and three CCTs as well as an on/off photocell.

CCT

3000K
4000K
5000K

ON/OFF PHOTOCELL

SMALL	MEDIUM		LARGE
30W	60W	100W	150W
25W	50W	85W	125W
20W	40W	70W	100W
15W	30W	50W	75W

Put light where it's needed.

The W22 wall pack adapts to its environment. One wall pack can do it all.

Trying to throw light to the far end
of your lot? Aim its light out.

Need light on the perimeter of your property but want
to minimize light trespass? Aim the W22's light down.

Control throw with the spin of a dial.

All models of the W22 include a tiltable light engine that allows you to adjust the forward throw.
Choose from 0, 15, 30, or 45° to control where the light gets thrown.

| 0° | 15° | 30° | 45° |

Available with smart controls.

The W22 is available with Lightcloud Blue wireless,
networked lighting control and sensing which can
be configured for daylight sensing and/or motion
sensing where brightness and hold time can be
adjusted for additional energy savings.

MVS SENSOR

DIMMING

SCHEDULING

Wire guard accessories.

W22-S-WG   W22-M-WG

W22-L-WG

Ordering Matrix

Product Family	Size		Wattage		Color Temp	Finish		Forward Throw		Driver		Controls		Battery Backup	
W22	-		-												
	S	Small	30*	30/25/20/15W	Blank 3000/4000/5000K	Blank	Bronze	Blank	Adjustable Throw 0°/15°/30°/45°	Blank	120-277V, 0-10V dimming	Blank	On/Off Photocell	Blank	None Battery Backup
	M	Medium	60**	60/50/40/30W		W	White	W		/480	480V, 0-10V dimming	/LCBS/MVS*	On/Off Photocell w/ Lightcloud Blue MVS Sensor	/E†	
	L	Large	100**	100/85/70/50W											
			150***	150/125/100/75W											

* S (Small) only, 30W in 480V for /LCBS/MVS is not available
** M (Medium) only
*** L (Large) only
† Battery backup only on M (Medium) and L (Large) models with 120-277V