INSTRUCTIONS Flush Mount



RAB Lighting is committed to creating high-quality, affordable, well-designed and energy-efficient LED lighting and controls that make it easy for electricians to install and end users to save energy. We'd love to hear your comments. Please call the Marketing Department at 888-RAB-1000 or email: marketing@rablighting.com

CRVFAS-XXR-XX-9CCT-UNV-W/EMBB

IMPORTANT

RAB fixture must be wired in accordance with the THIS PRODUCT MUST BE INSTALLED IN ACCORD.	XTURE. RETAIN THESE INSTRUCTIONS FOR FUTURE REFERENCE. ne National Electrical Code and all applicable local codes. ANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON
	ATION OF THE PRODUCT AND THE HAZARDS INVOLVED. DULD BE TURNED OFF AT THE FUSE BOX BEFORE INSTALLATION.
 Installation should be performed only by a clocal codes. WARNING – To prevent wiring damage or all INSTALLATION SHOULD ONLY BE PERFORM These instructions shall be included on an ir This device complies with Part 15 of the FCC 	Rules. Operation is subject to the following two conditions: rence, and (2) this device must accept any interference received, including
This equipment has been tested and found to comp limits are designed to provide reasonable protection and can radiate radio frequency energy and, if not in radio communications. However, there is no guaran harmful interference to radio or television reception try to correct the interference by one or more of the —Reorient or relocate the receiving antenna. —Increase the separation between the equipment a	bly with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These in against harmful interference in a residential installation. This equipment generates, uses installed and used in accordance with the instructions, may cause harmful interference to tee that interference will not occur in a particular installation. If this equipment does cause is, which can be determined by turning the equipment off and on, the user is encouraged to of following measures: and receiver. t different from that to which the receiver is connected.
WHAT'S IN THE BOX	INSTALLATION WITH J-BOX



- 1. Make sure the POWER IS TURNED OFF at the source to the J-box in which you are installing the product.
- 2. Disassemble the surface mount cover applying slight pressure to the cover and turn counterclockwise until the lens becomes unlocked and remove the cover. (Fig. 1)

Fig: 1



TOOLS NEEDED

Installation with J-BOX A screw driver is needed for installation

INSTRUCTIONS Flush Mount



RAB Lighting is committed to creating high-quality, affordable, well-designed and energy-efficient LED lighting and controls that make it easy for electricians to install and end users to save energy. We'd love to hear your comments. Please call the Marketing Department at 888-RAB-1000 or email: marketing@rablighting.com

INSTALLATION WITH J-BOX (cont'd)

3. Select desired CCT. (Fig.2)



4. Insert screws into J-Box holes, leaving about 15mm of space between the screw heads and J-Box. (Fig.3)



Fia: 4

Fig: 2



5. Wire the surface mount, white-white, black-black, brown connect to wall switch output wire, DIM+ purple connect input+, DIM- pink connect input-. Ground wire connect J-box input ground wire. Once wire connections are made, secure each with a wire nut. (Fig.4)





6. Lift fixture to ceiling and carefully tuck wires into J-Box. Align keyholes on surface mount with screws, then twist fixture until the screws engage the narrow end of the keyholes. Tighten screws to secure. (Fig.5)



INSTALLATION WITH J-BOX (cont'd)

7. Reassemble the surface mount cover by aligning the notches until the cover is flush with the housing and turn the cover clockwise until it locks in place. (Fig. 6)

Caulk around the mounting surface edge with silicone sealant. (Fig.7)







Test button and indicator light



\bigcirc

Emergency Application			
Wattage	Time	Initial Lumen	
4w	90 minutes	320lm	

Note[.]

1. The red light indicator will be on during charging. Press the test button while charging or after charging, the indicator light will be off and the fixture should operate at reduced lumen output. This means the emergency function is operating as normal.

2. The emergency driver will be fully charged after 24 hours of continuous charging. In case of a power failure, the Surface Mount fixture will operate for 90 minutes on emergency battery power.

3. When the Surface Mount is only powered by the emergency battery, press the test button twice continuously if need to turn it off. When the mains power is connected, it will automatically return to the normal mode.

TESTING PROCEDURES

1. Press the test button to cut the power to the AC driver and switch the system to emergency mode.

- 2. Release the test button to return to normal mode.
- 3. Switch off the circuit breaker to simulate a full power outage. Monthly
- 1. Ensure that the test button light is illuminated.
- 2. Conduct a 30-second discharge test by depressing the test button.
- 3. The LED load should operate at reduced output.

Annually

- 1. Allow a 24-hour charge before conducting test.
- 2.Ensure that the test button light is illuminated.
- 3. Conduct a full 90-minute discharge test.
- 4. The unit should operate as intended for the duration of the test.

"Written records of the testing shall be kept by the owner for inspection by the authority having jurisdiction."

SERVICING SHOULD BE PERFORMED BY QUALIFIED PERSONNEL.

Note: These instructions do not cover all details or variations in equipment nor do they provide for every possible situation during installation, operation or maintenance.



Fig: 5

Easy Answers rablighting.com

Visit our website for product info

Tech Help Line Call our experts: 888 722-1000

e-mail Answered promptly - sales@rablighting.com